

Voice Networking

Transit Out Call

System A
MPB1 IP : 192.168.10.1
STA 1XXX
Transit code : 4



Internet



PSTN or ISDN

System B
MPB1 IP : 192.168.10.2
STA 2XXX
PSTN Code 801

SYSTEM A

- 1) Assign Numbering Plan for Transit out code
 - **System Numbering Plan(PGM111)** :
Assign Transit out number (Prefix 4, Digit0)
- 2) Assign Networking Numbering Plan for Transit out code
 - **Networking Numbering(PGM321-3)** :
Assign transit out number
Numbering Plan Type : Transit Out
Numbering Plan Code : 4
Outgoing CO Group No : 03
AND Digit : 801 (CO Grp Access code for System B)
Digit Repeat : On (To send AND Digit)
CPN : MPB IP address for remote system

[System Numbering Plan]

Index	Prefix Code	More Digit (0-4)
1	1	3
2	2	3
3	3	3
4	4	0

[Networking Numbering Plan Table]

Select Index (1 - 250) :

Networking Numbering Plan Table Index 4

Attribute	Value	Range
Numbering Plan type	Transit Out	
Numbering Plan Code	4	Max 8 Digits(include '+', '#', 'X') [System Numbering Plan]
Outgoing CO Group No	3	1-72
AND Digit	801	Max 10 Digits
Digit Repeat	ON	
Digit Sending Mode	Overlap	
CPN INFORMATION 1	192.168.123.115	Enter IP Address
CPN INFORMATION 2	0.0.0.0	Enter IP Address
CPN INFORMATION 3	0.0.0.0	Enter IP Address
CPN INFORMATION 4	0.0.0.0	Enter IP Address
BLF Destination System IP Address	0.0.0.0	
BLF Destination System Port	9500	0-9999
Firewall Routing	OFF	

Voice Networking

Transit Out Call

System A
MPB1 IP : 192.168.10.1
STA 1XXX
Transit code : 4



Internet



System B
MPB1 IP : 192.168.10.2
STA 2XXX
PSTN Code 801

PSTN or ISDN

SYSTEM B

- 1) CO Group Access code
 - **CO Group Access code Attr(PGM180)** :
Set CO Group Access code (801)
- 2) CO COS
 - **CO COS (PGM177)**
Assign COS : COS 1 about incoming IP CO line.
- 3) CO to CO Call Attributes
 - **CO to CO Attributes (PGM179)**
Incoming CO Group – IP CO Line Group
Outgoing CO Group – PSTN CO Group
Incoming/Outgoing Direct : Enable

[CO Group Access Code Attributes]

Enter CO Group Access Code:

CO Group Access Code : 801

<input type="checkbox"/>	Attribute	Value	Range
<input type="checkbox"/>	Access Code Name	PRI	Max 16 Characters
<input type="checkbox"/>	CO Line Choice	Round	
<input type="checkbox"/>	Outgoing Group No	1	01-72, empty=not assign
<input type="checkbox"/>	AND Digit		Max 10 Digits
<input type="checkbox"/>	ARS Service	OFF	
<input type="checkbox"/>	ARS Digit 1	807	Max 8 Digits
<input type="checkbox"/>	ARS Digit 1 Usage	Use original digits	
<input type="checkbox"/>	ARS Digit 2		Max 8 Digits
<input type="checkbox"/>	ARS Digit 2 Usage	Use converted digits	

* Outgoing CO group no. must be assigned for ARS service.

[CO-to-CO Call Attributes]

Enter CO Group Number (1~72): First Second

CO Group No.		Attribute	Value	Range
First (3)	Second (1)			
Outgoing	Outgoing	Station	Enable	
		Attendant	Enable	
		Release Type	None	
		Release Time	60 *1sec	0-300
Incoming	Outgoing	Direct	Enable	
		Station	Enable	
		Attendant	Enable	
		Release Type	None	
		Release Time	60 *1sec	0-300